

# Data Sheet

## RENOLIT ALKORPLUS Sanitizer



### RENOLIT ALKORPLUS Sanitizer – type 81052 002:

#### Liquid for the sanitization of the swimming pool structure

##### Use:

The use of an **RENOLIT ALKORPLAN** swimming pool membrane will only give complete satisfaction when it has been installed on a clean structure. In the area between the support and the swimming pool membrane, there is frequently a build up of humidity. The additional presence of any organic matter will create a fertile breeding ground for microorganisms. **RENOLIT ALKORPLUS Sanitizer 81052 002** is a product that is suitable for the cleaning and disinfection the swimming pool support.

##### Description:

The sanitizing product comes in a 1 litre bottle and should be diluted in 9 litres of water. This dilution is then appropriate for the treatment of a normally sized private swimming pool (some 75 m2). The solution can be applied by brush or roller.

Read the safety data sheet carefully.

##### Application:

- **New swimming pools:**  
A newly installed swimming pool should be clean, but it is not sterile. The treatment with **RENOLIT ALKORPLUS Sanitizer 81052 002** will disinfect the supporting structure. Because of its long-lasting properties, the sanitizing treatment will also serve as a protection against subsequent contamination. Apply the diluted product to the support and allow it to dry before installing the membrane.
- **Renovation:**  
Old pools that have to be relined with a waterproof swimming pool membrane will generally be infected by micro-organisms and polluted with organic matter. An initial treatment with **RENOLIT ALKORPLUS Sanitizer 81052 002** will dissolve the organic matter and disinfect the structure.

After approximately 1 hour, the structure should be flushed and drained, to remove the pollutant. This cleaning operation should then be followed by a second treatment to complete the disinfection and to create long-lasting protection.

##### Infiltrations:

Infiltration of ground- or rainwater can introduce new organic matter and microorganisms between the support and the **RENOLIT ALKORPLAN** membrane. Therefore we recommend the repair of any cracks in the supporting structure before applying the **RENOLIT ALKORPLUS Sanitizer** treatment.